






somfy.com

RS485 RTS transmitter



Picture
no contractual


With the new Somfy RTS motor controller, you can manage all your Somfy applications easily using the same centralized home control system.




RS485 RTS TRANSMITTER

Functions


- Control the whole range of Somfy RTS products




Roman & pleated shades




Curtains




Venetian blinds



Roller shades



Awnings



Roller shutters


- Control up to 16 groups of products
- Can be controlled via:
 - RS485 ⁽¹⁾ - Dry contact / relays

⁽¹⁾The interface has its own network @

Technical specifications

Supply (Nominal / Frequency)	From 90V to 255V AC - 50/60 Hz
Amps	100 mA at 90V
	50 mA at 255V
RTS transmitter	433 MHz
	200m free field
	20m between 2 concrete walls
Connectors	RS485: 4 pin
	Dry contact: up to 5 3-pin 3.5mm detachable terminal blocks
	External antenna
Temperature	From 0°C to 60°C
IP20	
CE	

Wiring



Picture no contractual